

MODEL S-1800

(80kHz / 180kHz)

Technical Manual

SUZUKI FISH FINDER CO., LTD.
12-1 MAMIZUKA CHO, TOYOHASHI, AICHI
441-8007 JAPAN

PHONE: (81) 532 32-7511 FAX: (81) 532-32-7500
E-mail address: sales@suzukiff.co.jp
URL: <http://www.suzukiff.co.jp/>

Contents

Page

- | | |
|----|---|
| 3 | AFTER INSTALLATION |
| | DAILY MAINTENANCE AND INSPECTION |
| 4 | CAUTIONARY NOTES |
| 5 | FLOWCHART into ECHO DISPLAY |
| 6 | "WAITING" stays more than 2 minutes and then "CHECK FUSE AT CONTROL-BOX" appears next. |
| 7 | SELF CHECK SCREEN |
| 8 | The hoist does not raise or lower the soundome.
The hoist stops raising or lowering the soundome on the way, |
| 9 | HOW TO CHECK THE LIMIT SWITCH / THE SYMPTOMS OF FAULTY LIMIT SWITCH |
| 10 | Sonar Scanning stops intermittently. Sonar Scanning stops. |
| 11 | "WAITING" will appear more than 2 minutes and next "CHECK FUSE AT CONTROL-BOX" appears.
Normal Display does not appear on the screen even when Sonar Mode is set.
(HOIST NG) |
| | Scanning stops when Gain Dial/Far Gain Dial is turned.
Scanning stops when a Key is pressed. |
| 12 | No lighting of Sensor Lamp (LED) |
| 13 | LED does not light even if the Hoist is lowered.

Display does not change even if the tilt has been changed.
The depth readout is abnormal when Bottom Scanning is selected. |
| 14 | No Picture Display on the screen when scanning. |
| 15 | Only the surface echo is displayed.
The sensitivity is poor.
The picture does not change even if the Gain or Far Gain Control dial is turned. |
| 17 | Alignment for soundome cable connectors. |
| 18 | S-1800M10: Nothing appears on the screen when powered. |
| 19 | S-1800M10: Screen gets bright, but nothing appears

S-1800M10: Screen doesn't change into bright, even if the brightness dial is turned. |
| 20 | S-1800M10: The picture is unstable and scrolling vertically.

S-1800M10: Stripes appears to the left or right direction on the screen and no normal picture display.

S-1800M10: The specific colors do not appear on the screen. All screen changes into a specific color. |

Contents

Page

- | | |
|----|---|
| 21 | S-1800M15: No picture on display screen when powered. |
| 22 | S-1800M15: Screen gets bright, but nothing appears.

S-1800M15: Screen does not change into bright even if the bright dial is turned. |
| 23 | S-1800M15: The picture is unstable and scrolling vertically.

S-1800M15: Stripes appears to the left or right direction on the screen and no normal echo display. |
| 24 | S-1800M15: The specific colors do not appear on the screen. All screen changes into a specific color.

S-1800M15: Vertical phase is in a wrong position. Horizontal phase is in a wrong position. |
| 25 | The temperature readout is abnormal. |
| 26 | The audio monitor is not audible.

The memory data cannot back-up. |
| 27 | Key operation is not accepted.

"Beep" is not heard when a key is pressed. |
| 28 | Ship's speed cannot be displayed or abnormally displayed.
Navigational display does not appear on the screen. |
| 29 | Adjusting the Power Supply PCB (No.654) for S-1800M10 |
| 30 | Adjusting the Power Supply PCB (No.692) for S-1800M15 (MBB).

Confirming the voltage on the Power Supply PCB (No.694) for S-1800M15 (MBB). |
| 31 | Adjusting the voltage, 85V on the Power Supply PCB (No.703) for S-1800 Hull Unit |
| 32 | Adjusting the voltage, 70V on the Power Supply PCB (No.703) for S-1800 Hull Unit. |
| 33 | Main PCB for Monitor / Main PCB for Hull Unit |
| 34 | Power Supply PCB / TR PCB for Hull Unit |

DRAWINGS

BLOCK DIAGRAM

CIRCUIT DIAGRAM

WAVE FORMS

ASSEMBLY DRAWING

[AFTER INSTALLATION]

Check to ensure the voltage between the flange and the battery (negative) is lower than 0.65V.

If the voltage is high, connect the thick wire and make it lower than the regulated value.

The high voltage causes an electrolytic corrosion.

[DAILY MAINTENANCE AND INSPECTION]

For long-term trouble-free service, keep the unit away as much as possible from direct sunlight, moisture, dust, and shocks.

For keeping the equipment in good working order, check the following points regularly.

Is the power supply is compatible with the voltage rating of the equipment?

Model	Input Power supply
S-1800M10	DC10.5 ~ 40V
S-1800M15	DC20 ~ 30V
S-1800H80/180	DC10.5 ~ 30V

Dust or dirt must be removed from the equipment with a soft and dry cloth.

Be sure to use "display cabinet cover" to protect the unit from salt damage.

CAUTION

Do not use chemical cleaners to clean the equipment.

Remove oyster or barnacles attach on the soundome that result in poor sonar performance.

Tighten the screws of the mounting bracket, the flange, and the electrical connections.

The Hoist Gears and Flange Unit require regular lubrication with grease.

[CAUTIONARY NOTES]

Prior to doing any repair work, please check the items listed below.

Is the power supply voltage is normal?

Is the polarity (+, -) of a power supply correct?

Have any fuses blown out?

All the connectors wired correctly?

Securely tighten all connections.

Check to see if the connectors to individual boards are connected.

Check to see if the cable broke.

Check to see if there is any disordered appearance.

When conducting repair work, care should be taken as follows.

Make sure to turn the main power off before repair work and remove the power cable.

Due to the high voltage in the inverter unit, it is very dangerous to touch the peripheral lines.

C-MOS·ICs are on the boards. To avoid the damage by static electricity, do not wrap the board in any material that causes static electricity or do not use leaky soldering irons.

Do not place the board on a metal board since the battery is mounted on the board or some electric charge might remain on the condenser.


The following cases void its warranty and the high repair charge will be required.

<Changing the chip parts>


<Soldering on the board>

<Abnormal adjustment on the variable resistors>

[FLOWCHART into ECHO DISPLAY]



"WAITING" stays more than 2 minutes
And then "CHECK FUSE AT CONTROL-BOX" appears next.



SELF CHECK SCREEN

* By selecting the mode selection dial to MENU 2, "SELF CHECK" appears on the screen.

SELF CHECK

SELF CHECK

DATA-TX	OK...	Receiving the data between the Monitor unit and the Hull Unit.
DATA-RX	OK...	Transmitting the data between the Monitor and the Hull Unit.
DATA	OK...	Data transferred between the Monitor Unit and the Hull Unit.
HOIST	OK...	Hoist up and down
TILT	OK...	(Not available in this model)
TRAIN	OK...	Bearing direction control on the soundome
ROM-VER	OK...	P-Rom version of Monitor or Hull unit
OTHERS	OK...	(Not available in this model)

DATA-TX NG

Power Supply PCB for Monitor or for Hull unit (5V-2) is faulty.

Main PCB for Monitor or for Hull Unit is faulty. (C. Circuit: BUSY, ACK, REQ)

Signal cable is faulty

DATA-RX NG

Main PCB for Monitor or for Hull Unit is faulty. (C. Circuit: BUSY, ACK, REQ)

DATA NG

Main PCB for Monitor or for Hull unit is faulty. (C. Circuit: DIO 0 ~ DIO 3)

Signal cable is faulty

HOIST NG

Fusing at FUSE 2 for hoist motor

Hoist control circuit in Main PCB for Hull unit is faulty.

Hoist motor cable is faulty.

Limit Switch is faulty.

Hoist Motor is faulty.

TRAIN NG

Motor Control PCB for Hull Unit is faulty. (Train Control section)

Soundome is faulty.


Soundome cable is faulty.

ROM-VER NG

P-ROM version for Monitor or for Hull Unit is not correct.

The hoist does not raise or lower the soundome.

The hoist stops raising or lowering the soundome on the way.



FUSE

FUSE1	For the power supply circuit of the control unit.
FUSE2	For the Hoist motor
FUSE3	For the hoist circuit

When the fuse 1 blows, the Hoist raised the soundome, but does not lower it.

When the fuse 2 and 3 blow, the Hoist neither raises nor lowers the soundome.

Barnacles or oysters that adhere to the soundome will cause the soundome trouble.

Therefore remove them whenever they are found.

Also remove them when the ropes etc. got twisted round the soundome.

When overloaded, other than the fuse 2 the protect circuit in the monitor unit becomes active to protect the circuits or the hoist motor.

The circuit returns automatically after it is cooled down. For that the power should be kept OFF for a while.

Exchange the fuse 2 if it blows.

Disconnect the power when the Hoist could not raise or lower the soundome.

Otherwise this could damage the motors or Main PCB in Hull Unit.

HOW TO CHECK THE LIMIT SWITCH THE SYMPTOMS OF FAULTY LIMIT SWITCH

BEFORE MAINTENANCE AND INSPECTION (connected with the limit switch cables: red and black, brown)

Turn the breaker of your ship OFF. Remove FUSE 2.

Move the joint arm into the position between the upper limit switch and the lower limit switch with the crank handle.

UPPER LIMIT SWITCH / LOWER LIMIT SWITCH (connected with the limit switch cables: yellow and green)

Check the current flows between the points, "NO" - "COM" with the tester.

The following cases show the normal conditions:


- A short is found when the lever of the limit switch is pressed.
- An open is found when the lever of the limit switch is released.
- The following voltages are detected, with the FUSE 2 removed and the breaker of your ship ON.

When the plus lead of the tester is connected to "COM" and the minus lead is connected to "NO", if 0V is detected with the limit switch ON and approx. 7.3V with the limit switch OFF.

THE SENSOR LAMP FOR THE LIMIT SWITCH (connected with the limit switch cables: white and brown)

It is the ON/OFF switch of the sensor lamp for the monitor.

FIGURES OF LIMIT SWITCH CIRCUIT



THE SYMPTOMS OF FAULTY LIMIT SWITCH

UPPER LIMIT SWITCH CAN NOT BE SET "ON":

The hoist stops after going over the upper limit switch even if the power of the monitor is OFF.

The fuse 2 will blow, because the hoist motor circuit keeps working even if the hoist is stopped.

It damages the hoist motor circuit and hoist motor.

LOWER LIMIT SWITCH CAN NOT BE SET "ON":

When turning the power of the monitor on, the hoist starts to be lowered and reaches the lower damper rubber after going over the lower limit switch and then stops there.


The fuse 2 will blow, because the hoist motor circuit keeps working even if the hoist is stopped.

It damages the hoist motor circuit and hoist motor.

Some dust or dirt attached on the limit switch might be the cause of malfunction.

When the hoist is on the lower position than the upper limit switch, it is always raised after putting FUSE 2 back and turning the breaker of your ship ON. If the hoist stops on the halfway, another cause is suspected.

Sonar Scanning stops intermittently.
Sonar Scanning stops.



"WAITING" stays more than 2 minutes and then "CHECK FUSE AT CONTROL-BOX" appears next.
Normal Display does not appear on the screen even when Sonar Mode is set.
(HOIST NG)

Refer to the Hoist does not raise or lower the soundome.

Scanning stops when Gain Dial/Far Gain Dial is turned.
Scanning stops when a Key is pressed.

Refer to the "WAITING" stays more than 2 minutes.

[Bearing 0°and Scanning]

Bearing does not show 0°after Train starts.

Scanning starts after lowering the hoist and turning the Limit Switch on even if Bearing does not show 0°

"MENU 2" screen shows SELF CHECK -TRAIN NG

0°can not be adjusted while bearing.

Scanning is normal other than stopping temporarily.

"MENU 2" screen shows SELF CHECK -TRAIN NG

0°can not be adjusted and scanning stops occasionally.

"MENU 2" screen shows SELF CHECK -TRAIN NG only when the scanning stops intermittently.

Scanning is normal, though Train is inactive.

"MENU 2" screen shows SELF CHECK -TRAIN NG

[When Signal cable disconnected while operating.]

Hoist raises

Scanning stops


"MENU 2" on the screen shows:

SELF CHECK


DATA-TX	NG
DATA-RX	NG
DATA	OK
HOIST	OK
TILT	OK
TRAIN	OK
ROM-VER	OK
OTHERS	OK

No lighting of Sensor Lamp (LED)

* Turn off power to the Hoist system and keep the Hoist neither being lowered nor raised.




LED does not light even if the Hoist is lowered.




Display does not change even if the tilt has been changed.

The depth readout is abnormal when Bottom Scanning is selected.



No Picture Display on the screen when scanning.



[Transducer Disconnection]

Remove J2 in the TR PCB and set the tester to the 100M ohm or more range between the connector No.1 and No.3.


Connect the red or black lead of the tester alternately.

If it is normal, the indicator will move a little.


If the indicator will not move, the disconnection is suspected.

If there is a resistance value, seawater may invade the Soundome.


Only the surface echo is displayed.
The sensitivity is poor.
The picture does not change even if the Gain or Far Gain Control dial is turned.



* DUMMY RESISTANCE




120 / $0.0057 \mu F$
(180kHz)



160 / $375 \mu H$
(80kHz)

* OUTPUT WAVEFORM (Transducer - GND)




180kHz: 500Vp-p
(or 600Vp-p in case Power Supply PCB-85V)
80kHz: 535Vp-p
(or 650Vp-p in case Power Supply PCB-85V)


Use the over 10W and 1.5kV pressure-resistant dummy resistance.

Use the dummy resistance just for the confirmation of the output waveform.

Do not flow the current for a long time. Otherwise it will cause fire.



Alignment for soundome cable connectors



[Soundome Check by using a tester]

The temperature sensor is connected to the No.1 and No.2 pins of XHP-5 (5P connector) and it is normal when the resistance value of a temperature sensor at 25C., 5k ohm is covered.

In case of other temperatures


0	approx.17k ohm
10	approx.10k ohm
20	approx.6.3k ohm
30	approx.4k ohm

When Train Motor is normal, there is 25 ohm of resistance value between check pins No.1 (or No.2 to No.4) and XHP-10-B (10P connector) - No.5.

When Tilt Motor is normal, there is 21 ohm of resistance value between check pins XHP-10-B (10P connector) - No.10 and No.6 (or No.7 to No.9).


S-1800M10

Nothing appears on the screen when powered.




S-1800M10

Screen gets bright, but nothing appears



S-1800M10

Screen doesn't change into bright, even if the brightness dial is turned.



[BACKLIGHT FOR LCD UNIT]


When one side does not light, either the upper part or the lower part gets dark.

When both sides do not light, no picture is seen.

Contact your authorized dealers when replacing the backlights.


S-1800M10

The picture is unstable and scrolling vertically.



S-1800M10


Stripes appear to the left or right direction on the screen and no normal picture display.




S-1800M10

The specific colors do not appear on the screen.


All screen changes into a specific color.






S-1800M15

Screen gets bright, but nothing appears.




S-1800M15

Screen does not change into bright even if the bright dial is turned.




S-1800M15

The picture is unstable and scrolling vertically.



S-1800M15


Stripes appear to the left or right direction on the screen and no normal echo display.



S-1800M15

The specific colors do not appear on the screen


All screen changes into a specific color.




S-1800M15

Vertical phase is in a wrong position.


Horizontal phase is in a wrong position.




The temperature readout is abnormal.




OR




The audio monitor is not audible.



The memory data can not back-up.



Key operation is not accepted.




*


Some dust or dirt on the keys leads the switch ON.

Remove some dust or dirt to back to the normal state if key control.

"Beep" is not heard when a key is pressed.



Ship's speed can not be displayed or abnormally displayed.
Navigational display does not appear on the screen.




Adjust the Power Supply PCB (No.654) for S-1800M10
(Reckless adjustment may cause serious problem.)

Connect the digital tester to the 12V and GND-1 check pins and adjust VR4 so that the voltage is 12.0V.

Connect the digital tester to the 5V and GND-1 check pins and adjust VR5 so that the voltage is 5.0V.

Connect the oscilloscope to the FRQ and GND-P check pins and adjust the waveforms at VR2 so that the below is shown.

The value of frequency counter is 78.43 kHz.




Adjust the Power Supply PCB (No.692) for S-1800M15 (MBB)
(Reckless adjustment may cause serious problem.)

Connect the digital tester to the 5V-S and GND-S check pins and adjust VR3 so that the voltage is 5.0V.

Connect the digital tester to the 12V and GND-S check pins and verify the voltage is $12.0 \pm 0.6V$.

Connect the oscilloscope to the FRQ and GND-P check pins and adjust the waveforms at VR1 so that the below is shown.

The value of frequency counter is 56.0 kHz.



Confirming the voltage on the Power Supply PCB (No.694) for S-1800M15 (MBB)

Verify the voltage between +VOUT and -VOUT (GND-S) in the Power Supply PCB No.694 is 12.0.0V, +0.46V, -0.26V.

Adjust the voltage, 85V on the Power Supply PCB (No.703) for S-1800 Hull Unit
 (Reckless adjustment may cause serious problem.)

Connect the digital tester to the 15V and GND-1 check pins and adjust VR3 so that the voltage is 15.0V.

Connect the digital tester to the 85V and GND-1 check pins and adjust VR2 so that the voltage is 85.0V, when J3 connector is not connected.


Connect the digital tester to the 12V and GND-1 check pins and verify the voltage is $12.0 \pm 0.6V$.

Connect the digital tester to the 5V-1 and GND-1 check pins and verify the voltage is $5.0 \pm 0.25V$.

Connect the digital tester to the 5V-2 and GND-2 check pins and verify the voltage is $5.0 \pm 0.25V$.


Connect the oscilloscope to the FRQ and GND-P check pins and adjust the waveforms at VR1 so that the below is shown.

The value of frequency counter is 115.0 kHz.



Connect the oscilloscope to the 85V and GND-1 check pins and the Dummy Load between the J3-No.4 (85V) and No.3 (GND).

And adjust VR4 voltage rate that starts to degrease at 275 and keeps it not to degrease at 290 .



85V on the No.703 is designed to reduce the voltage when overloaded. 85V is output constantly when minimum loading. However carefully measure the changeable voltage on loading.

Verify the voltage by changing Power Reduction Control (TX POWER) as follows.

TX POWER	Voltage (V)
C	$61 \pm 3.0V$
B	$38 \pm 3.8V$
A	$22 \pm 5.0V$

Adjust the voltage, 70V on the Power Supply PCB (No.703) for S-1800 Hull Unit
 (Reckless adjustment may cause serious problem.)

Connect the digital tester to the 15V and GND-1 check pins and adjust VR3 so that the voltage is 15.0V.

Connect the digital tester to the 70V and GND-1 check pins and adjust VR2 so that the voltage is 70.0V, when J3 connector is not connected.


Connect the digital tester to the 12V and GND-1 check pins and verify the voltage is $12.0 \pm 0.6V$.

Connect the digital tester to the 5V-1 and GND-1 check pins and verify the voltage is $5.0 \pm 0.25V$.

Connect the digital tester to the 5V-2 and GND-2 check pins and verify the voltage is $5.0 \pm 0.25V$.


Connect the oscilloscope to the FRQ and GND-P check pins and adjust the waveforms at VR1 so that the below is shown.

The value of frequency counter is 115.0 kHz.



Connect the oscilloscope to the 70V and GND-1 check pins and the Dummy Load between the J3-No.4 (70V) and No.3 (GND).

And adjust VR4 voltage rate that starts to degrease at 150 and keeps it not to degrease at 160 .



Reference: Power Reduction Control (TX POWER)

TX POWER	Voltage (V)
C	$50V \pm 5\%$ (approx.47 ~ 53V)
B	$31V \pm 10\%$ (approx.28 ~ 34V)
A	$21V \pm 20\%$ (approx.16 ~ 25V)

[MAIN BOARD for MONITOR]

There are two types of the main boards, which are No.681and No.748.

The difference between No.681 and No.748 are circuit and some parts.

No.748 is interchangeable with No.681.

No.748 conforms to RoHS directive.

IMPORTANT NOTE for P-ROM

Ver. 2.1 or previous version of P-ROM works only on No.681 board.

Ver. 3.0 or latest version of P-ROM works on both No.681 and No.748 boards.

S-1800M10	Product label: S/No.0 - 1393 Product label: S/No.1394 - up	Main board is No.681. Main board is No.748.
S-1800M15	Product label: S/No.0 - 1486 Product label: S/No.1487 – up	Main board is No.681. Main board is No.748.
S-1800MBB	Product label: S/No.0 - 1349 Product label: S/No.1350 – up	Main board is No.681. Main board is No.748.

[MAIN BOARD for HULL UNIT]

There are two types of the main boards, which are No.691and No.751.

No.751 conforms to RoHS directive.

No.751 is interchangeable with No. 691. (However, caution should be taken on P-ROM.)

IMPORTANT NOTE for P-ROM

Ver. 2 or previous version of P-ROM works only on No.691 board.

Ver. 3 or latest version of P-ROM works only on No.751 board.


S-1800H80kHz	Product label: S/No.0 - 8075 Product label: S/No.8076 - up	Main board is No.691. Main board is No.751.
S-1800H180kHz	Product label: S/No.0 - 2222 Product label: S/No.2223 - up	Main board is No.691. Main board is No.751.

RoHS: **The Directive on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (commonly referred to as the Restriction of Hazardous Substances Directive or RoHS) was adopted by the European Union.**


【POWER SUPPLY PCB and TR PCB for HULL UNIT】

POWER SUPPLY PCB: NO.703

OLD




NEW



TR PCB: NO.685 -180kHz (In total 3 types, 2 old types and one new type)


OLD



There are 2 kinds on the
“No seal” type.

How to distinguish the type
U1: 3-terminalregulator
Circuit Diagram:
180kHz

NEW



There is one kind on the
“12dB seal” type.

Circuit Diagram:180kHz

How to distinguish the type
U1: Choke Coil
Circuit Diagram:
180kHz

TR PCB: No.685-80kHz

OLD


How to distinguish the type
U1: 3-terminalregulator
Circuit Diagram:
80kHz

NEW



How to distinguish the type
U1: Choke Coil
Circuit Diagram:
80kHz

S-1800M10
Monitor

S-1800H80/180
Hull unit




S-1800M10 Block diagram




S-1800M15
Monitor

S-1800H80/180
Hull unit



S-1800M15 Block diagram



モニター M10

- 回路図

S/NO.1000 番台は総合配線図が S-1800M10 です。

S/NO.2000 番台は総合配線図が S-1800M10A です。

- 波形図

MONITOR UNIT (M10)


CIRCUIT DIAGRAM


Circuit diagram is different based on the S/No. of S-1800M10.


S/No.1001 - 1999 S-1800M10

S/No.2001 - 2999 S-1800M10A

WAVE FORMS







NO. 688-BB Unused : VR3

NO. 688A-M10, BB : R2 39K
NO. 688A-M10-NEC : R2 3K

Title	CONTROL BOARD
Size	Document Number
B	NO.688A-M10 / NO.688A-BB


Sheet 1 of 1


Date: Thursday, March 25, 2010

Rev 2


No. 688A


MADE IN JAPAN
NO. 688A






BUHIN-S NO. 681B






**NO. 748**

NO.748

BUSY


CH1 : 「BUSY」 - 「GND」



CH2 : 「BUSY-M」 - 「GND」

REQ


CH1 : 「REQ」 - 「GND」



CH2 : 「REQ-M」 - 「GND」

ACK


CH1 : 「ACK」 - 「GND」




CH2 : 「ACK-M」 - 「GND」


N0.748


H-SYNC



V-SYNC








BUHIN-S NO. 654A

NO. 654A
MADE IN JAPAN




N0.654


電源入力 24.0V

D.C. IN: 24.0V


CH1 :「Q6 base」 - 「GND-P」



CH1 :「Q10 gate」 - 「GND-P」



CH1 :「Q7 base」 - 「GND-P」



CH2 :「Q7 emitter」 - 「GND-P」

CH1 :「Q11 gate」 - 「GND-P」




CH2 :「Q11 drain」 - 「GND-P」

N0.654

FRQ

CH1 : 「FRQ」 - 「GND-P」



モニター M15

・ 回路図

M15 は LCD-15 の背面シールの S/N. により回路図が異なります。

S/N.1000 番台は LC201 が LCD-A15CE

S/N.2000 番台は LC201 が LCD-A152GS(A)

S/N.3000 番台は LC201 が LCD-AD152CWH

S/N.4000 番台 / 5000 番台は LC201 が AA150XC03 と SSC-TA01A-SZK

・ 波形図

MONITOR UNIT (M15)

CIRCUIT DIAGRAM

Circuit diagram is different based on the S/No. of LCD-15.

S/No.1001 - 1999 LC201 is LCD-A15CE

S/No.2001 - 2999 LC201 is LCD-A152GS(A)

S/No.3001 - 3999 LC201 is LCD-AD152CWH


S/No.4001 - LC201 is AA150XC03 and SSC-TA01A-SZK


WAVE FORMS


VGA CABLE


BB UNIT

MONITOR UNIT













Title		LCD-15 (CD-AD152C) Internal connection		
Size Custom(Doc)	Document Number			
Date:	Thursday, May 29, 2008	Sheet	1	of 1
			Rev 3	



Title		LCD-15 (AA150XC03+SSC-TA01A-SZK) Internal connection		
Size Custom(Doc)	Document Number			Rev 4
Date:	Thursday, May 29, 2008	Sheet	1	of 1








N0.692

電源入力 : 24.0V


D.C. IN: 24.0V

CH1 : 「Q4 base」 - 「GND-P」




CH2 : 「Q4 emitter」 - 「GND-P」


CH1 : 「Q5 gate」 - 「GND-P」



FRQ


CH1 : 「FRQ」 - 「GND-P」







Title	POWER SUPPLY BOARD No.694		
Size	Document Number	Rev	
A4		0	

Date: Wednesday, May 26, 2004 Sheet 1 of 1





Title	SUZUKI FISH FINDER CO., LTD.	
Size	A4 Document Number	
Date:	Tuesday, November 23, 2004	Sheet 1 of 1
Rev	0	




ハルユニット

- ・回路図
- ・波形図 (180kHz)


HULL UNIT

CIRCUIT DIAGRAM


WAVE FORMS (180 kHz)




Rev 1	Sheet 1 of 1
Date: Thursday, April 01, 2010	Title: SUZUKI FISH FINDER CO., LTD.
Size A3	Document Number: S-1800 HULL-UNIT INTER CONNECTION
Page 1	Page 1 of 1




NO.691 MAIN BOARD





NO.751 MAIN BOARD

MADE IN JAPAN NO. 751




N0.751


設定：レンジ 120m

RANGE: 120m


CH1 :「BUSY」 - 「GND」




CH2 :「BUSY-H」 - 「GND」



CH1 :「REQ」 - 「GND」




CH2 :「REQ-H」 - 「GND」




HALL IC


CH1 :「J8 3pin」 - 「GND」


* Check pin: 85V






* Check pin: 70V





Title		S-1800 POWER SUPPLY BOARD NO.703B	
Document Number (Doc)	Date:	Size	Rev
A3	Wednesday, March 24, 2010	1 ft ²	1
	2009/03/16 2009/03/25 2009/03/17	1 ft ²	1




NO.703


電源入力 : 24.0V

D.C. IN: 24.0V


CH1 : 「U2 9pin OUT2」 - 「GND-P」




CH2 : 「U2 8pin OUT1」 - 「GND-P」



CH1 : 「Q3 drain」 - 「GND-P」



CH2 : 「Q4 drain」 - 「GND-P」





CH1 : 「Q5 drain」 - 「GND-P」


CH2 : 「Q6 drain」 - 「GND-P」

NO.703

CH1 : 「FRQ」 - 「GND-P」











Title: S-1800 TRANSCEIVER BOARD NO.0855 78MHz
Size: Document Number:
Date: Wednesday, April 07, 2010
Rev: 1


Title: S-1800












N0.685

設定：レンジ 120m パルス幅 x1


RANGE: 120m PULSE WIDTH: x1

CH1 :「J3 1pin TRIG」 - 「GND」




CH2 :「U2 13pin」 - 「GND」

CH1 :「Q7 base」 - 「GND」




CH2 :「Q7 emitter」 - 「GND」

CH1 :「Q3 gate」 - 「GND」



CH2 :「Q3 drain」 - 「GND」

CH1 :「J2 TD」 - 「GND」




NO.685

設定：レンジ 120m 感度補正 OFF TVG カーブ 30LOG パルス幅 x1

RANGE: 120m GAIN UP: OFF TVG CURVE: 30LOG PULSE WIDTH: x1


ツマミ：感度 0 GAIN DIAL: 0
遠感度 0 FAR GAIN DIAL: 0

CH1 :「U5 5pin」 - 「GND」



ツマミ：感度 10 GAIN DIAL: 0
遠感度 10 FAR GAIN DIAL: 0


CH1 :「U5 5pin」 - 「GND」




CH2 :「B」 - 「GND」

CH1 :「SIG」 - 「GND」

CH2 :「J5 1pin AUDIO」 - 「GND」





Title: MOTOR DRIVE BOARD

Size A Document Number
NO.633

Rev 0

Date: Monday, January 22, 2001

Sheet 1 of 1


N0.633

設定：ソナーモード


MODE DIAL: 360 ° ROTATION DISPLAY

J1 コネクター側


CH1 :「J1 1pin TRCK1」 - 「GND」



CH2 :「J1 2pin TRCK2」 - 「GND」



CH1 :「J1 1pin TRCK1」 - 「GND」



CH2 :「J1 4pin TRCK4」 - 「GND」


N0.633

設定：ソナーモード


MODE DIAL: 360 ° ROTATION DISPLAY

J2 コネクター側


CH1 : 「J2 1pin TRMOT1」 - 「GND」



CH2 : 「J2 2pin TRMOT2」 - 「GND」



CH1 : 「J2 1pin TRMOT1」 - 「GND」



CH2 : 「J2 4pin TRMOT4」 - 「GND」


N0.633

設定：サイドスキャンモード


MODE DIAL: BOTTOM-SCAN DISPLAY

J1 コネクター側


CH1 : 「J2 5pin TLCK1」 - 「GND」




CH2 : 「J1 6pin TLCK2」 - 「GND」



CH1 : 「J1 5pin TLCK1」 - 「GND」



CH1 : 「J1 5pin TLCK1」 - 「GND」




NO.633

設定：サイドスキャンモード


MODE DIAL: BOTTOM-SCAN DISPLAY

J2 コネクター側


CH1 : 「J2 6pin TLMOT1」 - 「GND」




CH2 : 「J2 7pin TLMOT2」 - 「GND」



CH1 : 「J2 6pin TLMOT1」 - 「GND」



CH2 : 「J2 8pin TLMOT3」 - 「GND」



SUZUKI FISH FINDER CO., LTD.

S-1800 HOIST-UNIT INTER CONNECTION

Title

Rev

S-1800 HOIST-UNIT INTER CONNECTION

Document Number

{Doc}

3

Date: Tuesday, April 27, 2004

Sheet 1 of 1

記号	内容	設計	日付
1	線色: 茶 黒、外径: 6 7 ケーブル品番 (P-7) 長度 -	G02-039	H14/07/30
2	300501 / REC PLUG, 300502 / PLUG REC	G02-076	H14/10/21
3		G03-071	H15/07/08

モニター M10

・組立図

S/N0.1000 番台は S-1800M10 で組立図は「35165C」です。

S/N0.2000 番台は S-1800M10A で組立図は「36323C」です。


MONITOR UNIT (M10)


ASSEMBLY DRAWING

Assembly drawing is different based on the S/No. of S-1800M10.


S/No.1001 - 1999 S-1800M10


S/No.2001 - 2999 S-1800M10A







△	△	「G 03-016」による変更	03/01/27	東川
記号	処理	訂改	日付	担当
—	—	尺度	検査図	承認
—	—	設計	—	—
S-1800M10 (F119)	機種名	名稱	番号	品別
		組立図	35165C	—
		(—)		3/3







△記号	処理	改訂	尺度	設計	製図	検査	日付	担当	承認
—	—	—	1 : 4	—	09/07/09	09/07/16	09/07/17	—	—
—	—	(—)	—	—	—	—	—	塩瀬	笹野
S-1800M10A (F119)	組立図 (—)	名稱 組立図	外寸	図面番号 36323C	品別 —	業別 —	3 / 3	3 / 3	3 / 3



モニター M15

・組立図

M15 は LCD-15 の背面シールの S/N. により組立図が異なります。

S/N.1000 番台は「35215C」

S/N.2000 番台 / は「35358C」

S/N.3000 番台は「35532C」

S/N.4000 番台 / 5000 番台は「35358C」  : SSC-TA01A-SZK

MONITOR UNIT (M15)

ASSEMBLY DRAWING


Assembly drawing is different based on the S/No. of LCD-15.

S/No.1001 - 1999 35215C


S/No.2001 - 2999 35358C

S/No.3001 - 3999 35532C


S/No.4001 - 35358C  .SSC-TA01A-SZK




△	「G 03-095」による変更 記号	改訂	03/09/18	東川
材質	処理	尺度 計 設 計	製図 日付	担当 承認
-	-	1:4 (-)	- 02/12/17 東川	02/12/17 岩崎
機種名	名称	図面番号	検査 品別	別業
LCD-15 (-)	組立図 (LCD-A15CE)	35215C	-	1/4




△記号	-	改訂	尺度	設計	製図	検査	日付	担当	-	-
材質	処理									
-	-		1 : 4	-	02/12/17	02/12/17	02/12/17	岩崎	笹野	
機種名	名稱	組立図	(LCD-A15CE)			図面番号		品別	葉別	
LCD-15 (-)	LCD-15 (-)	組立図	(LCD-A15CE)			35215C	-	2 / 4		






△	記号	G 03 - 112による変更 訂	尺 度	設 計	製 図	検 図	日付	担当
材 質	処 理							承 認
—	—	1 : 4	(-)	—	03/08/29	03/09/15	03/12/08	東川
—	—	—	—	—	—	—	—	塩瀬


LCD-A152GS (A)




△記号	-	理	改	訂	計	製	検	日付	担当
材質	-	処理	尺度	設	計	製	検	-	-
機種名	(-)	名稱	(-)	-	-	04/12/03	04/12/06	04/12/06	承認
LCD-15	(LCD-AD152CWH)	組立図	35532C	-	-	35532C	-	1/4	葉別



△記号	処理	尺度	訂	計	製図	検図	日付	担当
—	—	1 : 4	(-)	—	04/12/03	04/12/06	04/12/06	梶野
—	—	—	—	—	—	—	—	葉別
LCD-15 (-)	組立図 (LCD-AD152CWH)	35532C	—	—	—	—	—	2 / 4




△記号	処理	寸度	訂	設計	製図	検図	担当
—	—	1 : 4 (-)	-	03/08/29	03/09/15	03/09/15	承認
—	—	—	—	東川	塩瀬	塩瀬	梶野
LCD-15 (-)	名稱 組立図	面番号	品別	—	—	—	葉別
	35358C	—	—	—	—	—	1 / 4




△	記号	G 03 - 112による変更 処理	改訂	尺度	設計	製図	検査	担当
材質	-	-	-	1 : 4	(-)	03/08/29	03/09/15	東川 塩瀬
機種名	LCD-15	組立図	名稱	面番	号	品別	葉別	鈴木


35358C - 2 / 4



△ △ △	「G 0 3 - 0 2 5」による変更 「G 0 2 - 0 9 2, G 0 2 - 1 0 2」に による変更 「G 0 2 - 0 8 9」による変更	03/02/13 02/12/19 02/11/08	東川 東川 東川
記号	訂正 改訂	日付	担当
材質	処理	尺度	検査
-	-	1:3 (-)	02/10/11 東川
機種名	名称	図面番号	承認 塩瀬 笹野
S-1800MBB (F116BB)	組立図 (-)	35166C	別業
		-	1/3



No. 688 完成品



△	「E 03-071」による変更	03/08/11	東川
△	「G 02-092」による変更	02/12/19	東川
記号	改訂	製図	担当
—	1:3 (-)	—	検査
材質	処理	設計	付
—	—	—	—
機種名	名称	面番号	品別
S-1800MBB (F1116BB)	組立	35166C	2/3
	(-)	—	

△タイ


輸出

13

11


12

x5
101



△	裏銘板位置修正 による変更	「G 02-092, G 02-102」に	03/10/02	東川
△	記号	処理	尺度	訂正
—	—	—	1:3 (-)	設計
—	—	—	—	製図
S-1800MBB (F116BB)	機種名	名称	日付	検査
		組立	02/10/11	担当
		(-)	02/10/11	承認
			02/10/11	塩瀬
			02/10/11	笹野
			—	葉別
		35166C	—	3/3

本図面は「S-1800MBB」の装備品を示す




△記号	-	改訂	尺度	設計	製図	検査	担当
材質	処理						承認
機種名	名称	組立図	図面番号	図面番号	品別	葉別	
-	-	1 : 4 (-)	-	03/08/29 (-)	03/09/15 (-)	東川 塩瀬	笹野
LCD-15 (-)	組立図	35358C	-	4 / 4			

ハルユニット

・組立図


HULL UNIT

ASSEMBLY DRAWING




△	改訂指示書「G07-045」による変更 記号	07/06/15	東川
材質	処理 尺度 設計 製図	日付	担当
機種名	名称	検査	承認
S-1800H80, 180 (F116B)	組立図	塩瀬 委託	08/04/01 笠野
		08/03/31	08/04/01
		品別	葉別
		35080C	

金木魚探株式会社




△	改訂指示書「G04-006」による変更 記号	訂	04/06/05	東川
材質	処理	尺度	設計	製図
機種名	名称	図面番号	検査	承認
S-1800H80, 180 (F116H)	組立図 (木イスト)	02/06/22 委託	08/03/31 塩瀬	08/04/01 笠野
				葉別
				1/3 35081C



△ 改訂指示書 「G05-046」による変更						05/08/19	東川
記号	処理	尺度	設計	製図	検査	日付	担当
						02/06/22 委託	08/03/31 塩瀬
							08/04/01 笠野

材質	名稱	組立図	面番号	品別	葉別
S-1800H80, 180 (F16H)	組立図 (木イスト)	35081C			

2/3



本図面は装備品を示す